

Date: February 2, 2006

T-Link TL300 Quick Installation Guide

TL300

The T-Link TL300 connects directly to the telephone output of a control panel and simulates a telephone connection, providing a UDP Internet connection. The T-Link TL300 on-board zones can be used as in mode 2 (4-zone stand-alone) and mode 3 (12-zone stand-alone). Modes 1, 4 and 5 are not supported.

STEP 1 - Resetting to Factory Defaults

Hardware Defaults

- Remove Power from the T-Link TL300; disconnect battery and control panel if applicable
- Connect a jumper wire between the PGM1 and IN1 terminals
- Apply power to the system
- Wait approximately 20 seconds then remove the short between PGM1 and IN1.

The T-Link TL300 can be Defaulted through the panel keypad

- Enter Section [999] of the T-Link TL300
- Enter data [00] to default the unit to factory settings
- Enter data [55] to restart the unit.

STEP 2 - TL300 Panel Installation

- Secure the T-Link TL300 module to the side of the cabinet of the control panel or install the T-Link TL300 in a DSC enclosure (model PC5003C). Refer to Appendix B: T-Link TL300 Compatibility Chart for a list of panels supported
- Wire the panel's 12VDC and GND terminals of T-Link TL300 or Power unit with a 12VDC, 225 mA UL Listed Power supply.
- Wire the panel's TIP and RING terminals to the T1 and R1 terminals of T-Link TL300.
- Apply AC and DC to the main control panel. Both the T-Link TL300 and the panel will power up.

NOTE: A restart is required for the programming changes to take effect. Allow up to 15 seconds for a restart.

All additional programming is done through the TLink Console Software. Please see the TLink Console software manual for and further programming instructions.

Specification	
Input Voltage	12 VDC
Input Current	T-LINK TL300 Max current draw: 360mA
Dimensions	3.25" x 5.25" (8.3 cm x 13.3 cm)
Operating Temperature	32°-122°F (0°-49°C)
Output Protocols	UDP/IP 10/100 BaseT half duplex
Input Protocols	Contact ID protocol
Digital Inputs	4-digital inputs (can be increased to 12 using the PC5108)
Connectors	4-pin header for the PC-Link and RJ-45 for Ethernet, DVACS adaptor (DVACS kit only)
Programming	Panel keypad, console on the RS232 or remote T-Link console
Network	Ethernet LAN/WAN 10 BaseT or 10/100 BaseT
E-mail	sends alarm messages to maximum 2 E-mail addresses
Downloading Support for DSC Panels	DLS-3 and/or System Administrator software
Multiple Central Stations	primary and backup via phone line (NOT available for DVACS installations).
Call Direction Options	primary or backup communicator using panel call direction (NOT available for DVACS installations).
Approval Listings	UL (Grade of Service AA, Encrypted Line Security) ULC (Signal Channel Security Level 4/5) FCC, IC, CE