



SETTING UP A DW SPECTRUM® CAAS™ SERVER

NOTE: Before setting up your DW Spectrum® CaaS™ server for recording via the DW Spectrum® client software, write down the camera/server's IP address for identification and configuration.

To locate your camera/server's IP address:

1. Launch the DW IP Finder software on a computer located on the same network as the camera/server.
2. Click on the 'Search' button. The software will scan your network for all supported cameras and display the results in the table. Allow up to 5 seconds for the IP Finder to find the camera on the network.
3. Locate your camera/server on the results list and write down its IP address.



NOTE: DW Spectrum® CaaS™ servers run Edge version and come with 1 DW Spectrum® Edge license.

A. FINDING YOUR DW SPECTRUM® CAAS™ CAMERA/SERVER

STEP 1: Launch the DW Spectrum® IPVMS client on a computer running on the same network as the DW Spectrum® CaaS™ server. Please note that the client and all the DW Spectrum® CaaS™ servers you are connecting to must be on the same network. It is not recommended to try to merge DW Spectrum® CaaS™ servers from different networks.

STEP 2: If the CaaS™ server is not showing in the tile, click on the "Connect to Another Server..." button at the bottom of the screen.




STEP 3: Enter the DW Spectrum® CaaS™ server's IP address, port (default is 7001), username and password (default are admin | admin12345). You may test the connection to make sure you have entered the proper information, or click OK to log into the DW Spectrum® CaaS™ server.




Attention: This document is intended to serve as a quick reference for initial set-up.
See the DW Spectrum® IPVMS full manual for more information on features and functionality.

B. CONFIGURE RECORDING


- STEP 1:** Right-click on the DW Spectrum® CaaS™ server from the resource tree to set up recording, then click “Camera Settings”.
- STEP 2:** Go to Recordings tab.
- STEP 3:** Click  to turn on recording.
- STEP 4:** Configure schedule settings for quality, FPS and recording type.
- STEP 5:** Click and drag mouse over the recording schedule to apply the settings to multiple days and hours.



* Click on All to apply to the all schedules.



- STEP 6:** A red dot will appear next to the camera in the resource tree when recording is started.



NOTE: For recording estimation and times, see DW’s IP calculator. Go to www.digital-watchdog.com > Support > Calculators

NOTE: NAS storage options are available for external storage. Refer to the Blackjack® NAS QSG for additional information on how to configure the Blackjack® NAS storage with the DW Spectrum® CaaS™ server.

NOTE: You can install up to 30 DW Spectrum® CaaS™ servers on the same system/network. (DW Spectrum 4.0 or higher).