



PC5320 Multiple Wireless Receiver Module

- Multi-frequency support for combination of 900/433 MHz receivers
- Compatible with PC1616, PC1832 and PC1864 PowerSeries control panels
- Can be used to connect up to 4 wireless receivers for increased coverage

Available in NA, LATAM, EMEA and APAC



PC5100 PowerSeries Addressable Zone Expander

- Connect up to 32 addressable detectors (AML)
- Detectors can be home-run, t-tapped or daisy chained
- Easy detector enroll process
- Compatible with PC1616, PC1832 and PC1864 control panels

Available in NA, LATAM, EMEA and APAC



PC5108 PowerSeries 8-Hardwire Zone Expander

- Adds 8 hardwire zones
- AUX power, 125 mA (PTC protected)
- Compatible with PC1616, PC1832 and PC1864 control panels


Available in NA, LATAM, EMEA and APAC



PC5200 & PC5204 PowerSeries Power Supply Modules

- Fully supervised for AC failure, low battery and AUX failure
- PC5204 adds 4 programmable high current voltage outputs: rated at 1 Amp @ 12 VDC, output #1 can be used as a supervised bell output
- Compatible with all PowerSeries control panels
- Connect one PC5204 and up to four PC5200 supervised modules on a system
- Provides up to 1 Amp @ 12 VDC
- Compatible with PC1404, PC1616, PC1832 and PC1864 control panels

Available in NA, LATAM, EMEA and APAC



PC5208 PowerSeries Programmable Output Module

- Provides 8 low current (50 mA) PGM voltage outputs
- Compatible with PC1616, PC1832 and PC1864 control panels

Available in NA, LATAM, EMEA and APAC