# Residential 7251/7351 Slide

Slide Gate Operator

## **Superior Solar Power**

Post or pad mount gate operator for residential, farm and ranch slide gates.



**7251**: 1050US Board, post mount

**SYSTEM DESIGN SUPPORT:** Contact Nice/HySecurity for help with custom site requirements, CAD drawings, tech manuals or other specifications support.

**VISIT WWW.HYSECURITY.COM** for installation manuals, parts diagrams, wiring diagrams, specifications, image gallery, videos, training and much more.







# Residential, Farm, Ranch



#### Advanced 1050 control board for 7251/7351

- Simple to install and configure
- Supports up to 1,000 Inti or Era One remotes with rolling-code security
- Nice BlueBUS 2-wire technology self-identifies monitored photo eyes
- Smart battery charging management
- Full featured controller configures over 100 different parameters
- LCD display for detailed user feedback
- Internal 7 day programmable timer
- Surge protection
- Built in solar regulator and charger

### 7251/7351 Models, AC or Solar

Model	7251 - Post Mount	7351 - Pad Mount
Duty Cycle	Varies based on charging capacity*	
Drive	Electromechanical	
Rate of Travel	1 ft/sec (30 cm/s)	
Gate Length Max.	25 ft (7 m)	
Gate Weight Max.	800 lb (362 kg)	
Temperature Rating	-4° to 122° F (-20° to 50° C)	
Operating Voltage	12VDC	
Input Voltage	12 - 30VDC	
Idle Current	10mA	
Accessory Power	.3А	
User Controls	1050US board	
Relays	2 programmable relays	
Enclosure	22w x 22h x 15.5d inch (56w x 56h x 39.4d cm)	20.5w x 26.5h x 18d inch (52w x 67.3h x 45.7d cm)
Finish	Powder coated black	
ETL Listed (UL 325)	Usage Class I, II	
Warranty	2 year	

<sup>\*</sup> Actual battery backed up cycles will depend on gate resistance to travel, cycle length, battery health, ambient temperature, accessory power draw and frequency of gate cycles during power outage.

Note: Battery and battery charger or solar panel required for operation, not included. Nice recommends a 30-35Ah battery for AC applications and a 70Ah or larger battery for solar applications. For more information on solar applications see www.hysecurity.com/solar

To enable fully automatic operation, all SLIDE gate operators require a minimum of TWO monitored external entrapment protection sensors (one for each direction) to protect entrapment zones in both the open and close direction of travel. Visit www.hysecurity.com/gatesafety for more information on UL 325 standards and gate safety.

#### Optional Accessories - See website for complete list



EPMB/A EPMOB/A EPLOB/A Photo Eye Kits



EDSWG/A Keypad



Oview Programmer



Inti 2-Channel Transmitter



Era One 2 or 4 Channel Transmitter



Solar Panels



Battery Charger



**ASO Edge Sensors** 







